




SP-002.5 Power Pack

SA-1-002.5
Piston
Housing
Assembly



SA-4-002.5 Valve Assembly
(not included in foot model)

SA-3-002.5
Piston
Shaft
Assembly

SA-1	Piston Housing Assembly	SA-1-002.5	
1-F	Piston Housing Remote	1-F-002.5	
3	Piston Shaft	3-002.5	
5	Piston Lock Plate	5-002.5	
6	Safety Lever Assembly	DA-1	

7	Spool	7-002.5	1
8	2 Spool O-rings (Kit of 10)	16-003-K10	1
9	Spool Spring	9A-01	1
11	Snap Ring	11-01	1
14	End Cap	14-002.5	
15A	Front Piston Seal	15A-002.5	
15B	Rear Piston Seal	15B-002.5	
16	2 O-rings (Kit of 10)	16-01-K10	
17	O-ring (Kit of 10)	17-002.5-K10	
18	O-ring	18-002.5	
19	Divider Seal (Kit of 10)	19-002.5	
22	Valve Spacer	22-02	1
24	Valve Washer	24-01	1
25-H	Hex Cam	25-H	
30	Piston Snap Ring	30-002.5	
33	2 Screws (Kit of 10)	28-01-K10	
34	Piston Seal	18-01	
35	O-ring (Kit of 10)	35-002.5-K10	
36A	Front Piston Plate	36A-002.5	
36B	Rear Piston Plate	36-002.5	
	VALVE REPAIR KIT	SA-4-002.5	

(1) Included in the valve repair kit.
 • Optional Cams available, for use with special tools: 25-C-800, 25-F, 25-S, 25-R, 25-C
 • Two hoses included with FOOT models, one with HAND models