


## **SP-01P Power Pack**





SA-1	Piston Housing Assembly	SA-1-01	
1-F	Piston Housing Remote	1-F-01F	
2	Jaw Housing	SA-2-01	
3	Piston Shaft	3-01P	
5	Piston Lock Nut	5-01	
7	Spool	7-01	1
8	Spool O-ring	16-003-K10	
9	Spool Spring	9A-01	1
11	Snap Ring	11-01	1
15A	O-ring Piston Seal	15A-01	
16	O-rings (2 required)	16-01-K10	
17	O-Ring	17-01-k10	
18	O-ring	18-01	
22	Valve Spacer	22-01	1
23	Pivot Screw	23-01	
24	Valve Washer	24-01	1
25	Piston Washer	25-01	
28	2 Screws	28-01-K10	1
33	Insert Nut	33-01	
40	Dual Action Lever	DA-1	
	Valve Repair Kit	SA-4-004	Ì

## (1) Included in the valve repair kit.

Two hoses included with FOOT models, one with HAND models